

Cuadro Dekorarte para Sublimación

Instrucciones de estampación para lienzos Print & Fold

- 1-Colocar el lienzo dentro de la plancha.
- 2-Colocar la impresión sobre el lienzo.
- 3-Estampar durante 60 segundos a 200°C el lienzo de A4 (28,5cm x 19,5cm) y A3 (40,5cm x 28,5cm), estampar durante 90 segundos a 200°C el lienzo de A2 (48,5cm x 37,5 cm)
- 4-Una vez estampado, doble los cuatro laterales hacia atrás y grápalos en las esquinas.

Instructions estampage pour la toile Print & Fold

- 1 -Place de la toile à l'intérieur de la plaque .
- 2 -Place l' impression sur toile .
- 3-Estampar Pendant 60 secondes à 200°C toile A4 (28,5cm x 19,5cm) et A3 (40,5cm x 28,5cm) , estampage pendant 90 secondes à 200°C canvas A2 (48,5cm x 37,5 cm)
- 4-A Le temps d'impression , doubler les quatre a rière et les agraffer dans le coins.

Instruções de estampagem para a lona Print & Fold

- 1- Coloque a tela no interior da placa .
- 2 - Coloque a cópia na lona .
- 3-Estampar Durante 60 segundos a 200°C canvas A4 (28,5cm x 19,5cm) e A3 (40,5cm x 28,5cm) , carimbando durante 90 segundos a 200°C lona A2 (48,5cm x 37,5 cm)
- 4-A O tempo de impressão , dobrar a quatro verso e grampeá -las no cantos .

Instructions stamping for canvas Print & Fold

- 1 - Place the canvas inside the plate.
- 2 - Place the print on canvas.
- 4-Estampar For 60 seconds at 200°C canvas A4 (28,5cm x 19,5cm) and A3 (40,5cm x 28,5cm) , stamping for 90 seconds at 200°C canvas A2 (48,5cm x 37.5 cm)
- 4-A Print time, double the four side back and staple them in the corners .



1



2



3